

 **GROUND SYMBOL; ANY TIME YOU SEE THIS SYMBOL ATTACHED TO A WIRE, THAT WIRE NEEDS TO BE SOLDERED TO GROUND** (Ground points are usually soldered to the back of the volume or tone pots or to any central ground point on the guitar; The central ground usually comes from a wire attached to the bridge of the guitar)

 **SOLDER POINT SYMBOL; THIS SYMBOL REPRESENTS THE PLACE AT WHICH TO SOLDER THE WIRE(S) TO THEIR CONTACT POINTS**



TAPPED STRATOCASTER

COPYRIGHT 2001 SEYMOUR DUNCAN / BASSLINES
 STRATOCASTER IS A REGISTERED TRADEMARK OF FENDER MUSICAL INSTRUMENTS

