

FENDER "PRINCETON" LAYOUT

MODEL 5F2

A-EF

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMETER.
VALUES SHOWN + OR - 20%

